


Installing & Activating AFT Leases

Leases provide a license to use the selected AFT software for the purchased lease term. They may be installed either from an AFT CD or using files downloaded from www.aft.com. These instructions describe both options.

1) Install Application

To run setup from an AFT CD, insert the CD into your drive and, when the setup menu appears, select *Install Full Software*, select the software to be installed and click *Install Selected Product*.



AFT Fathom shown for example only. Be sure to select the application you are installing.

To run setup using downloaded files, the following files must be downloaded using the links below:

- [Copy Protection Setup](#)
- The application setup from the following table on page 2 for the software lease purchased.
- If a Network or Global license is being installed, also download the related Network Client Setup.

Download all files into separate, empty folders on your harddrive.

Note: If you already have a licensed AFT Fathom or AFT Arrow installation and are installing one or more Fathom or Arrow Add-on Modules, no application installation is required.

Skip to *Install the Lease License*.

Application Setup	Network Client Setup*
AFT Arrow 4	AFT Arrow Network Client Setup
AFT Fathom 7	AFT Fathom Network Client Setup
AFT Impulse 4	AFT Impulse Network Client Setup
AFT Mercury 5	AFT Mercury Network Client Setup
AFT Titan 3	AFT Titan Network Client Setup
Chempak Property Database 1	n/a
AFT Chempak Viewer 2	Chempak Network Client Setup
AFT Chempak Add-in for Excel 2	Chempak Network Client Setup
AFT Engineering Utility Suite 2	AFT EUS Network Client Setup
AFT SteamCalc 2	AFT SteamCalc Network Client Setup

* Network installation only

To install the application double click the downloaded application setup.

For stand alone licenses a *Stand Alone* installation type will be chosen, which installs the application on the local harddrive.

For network and global licenses either a *Stand Alone* or *Network* installation type may be chosen (the license will be installed on a server regardless of what application installation type is chosen).

A *Network* installation type installs the main application files on a server. After installing on the server, complete the application installation by:


- i. Copy or move the downloaded network client setup file to the *NetworkClientSetup* folder below the application folder on the server,
- ii. From each client, browse to the server and run the downloaded client setup placed in the *NetworkClientSetup* folder.

When the *Setup Type* window appears, select the installation type according to the lease license purchased and, for network and global licenses, the preferred installation configuration. When the *Enter Registration Serial Number* window appears, enter your name, company and the license number provided on the license agreement supplied with your order:

Note: *AFT Arrow and AFT Fathom Add-modules and Chempak Property Database do not require a license number to be entered.*


2) Install the Lease License

If installing from an AFT CD, insert the CD into your drive, select **Install Copy Protection** and click *Install Selected Product*.




If installing from downloaded files, run the Copy Protection Setup downloaded from the website. If an *Open File - Security Warning* appears, click *Run* to continue.

When the “Welcome to the InstallShield Wizard for AFT Application Copy Protection” window appears, click *Next* to continue and select **CrypKey License (needs activation)** and click *Next*.




When the Crypkey Installation Action window appears, select *Install the Crypkey License*.



Continue in the following windows by accepting the default selection and clicking *Next* or *Yes* as appropriate. The Crypkey folder created on the server must be shared (read/write) to all users.

NOTE: For network licenses *CopyProtectionSetup* must also be run on each client computer selecting *Crypkey License (needs activation)* at the Copy Protection Type window and *Install Crypkey Components on Client PC (Network License Only)* at the CrypKey Installation Action window.



Additionally for Crypkey network license installations the control.aft file in the application folder will need to be opened in Windows/Notepad and edited to add the path to the Crypkey folder on the server as shown in the following example:

[SEARCH PATHS]
CrypKeyPath = [\\servername\CrypkeyPath](#)



Where "servername\CrypkeyPath" is replaced with your server name and the path to the Crypkey folder on your server. If a network installation was chosen for the application, then editing of the control.aft file will only be required on the server. If a stand alone installation was chosen the control.aft file on each client must be edited.

After successfully installing the Crypkey license, the *Crypkey Activation* form will appear. Complete the information fields and select the AFT products for which the lease license(s) are being installed.

Note: For network license installations this only applies to the Crypkey installation on the server.

The information entered in this form will be saved to *CrypkeyActivation.txt* in the C:\AFT Products\Crypkey folder. Send this file to sales@aft.com by either clicking **Send Email** or clicking **Save File** and manually generating an email and attaching the file.


When you click **Send Email**, Setup will attempt to send the *CrypkeyActivation.txt* file using your email client. If the automatically generated email is successful, the "Crypkey Successfully Installed" message appears. Click "OK" and "Finish".



Note: If the automatic email attempt fails, a message appears instructing you to manually attach the file to an email and send it to AFT. The *CrypkeyActivation.txt* file will be found in your *c:\AFT Products\Crypkey* folder.

3) Activate the Lease License

You may proceed with activation after receiving the license file from AFT (via email) and saving the attached .clf file to your *AFT Products\Crypkey* folder.



Note: When saving the file attachments the message "CrypkeyActivation.txt. A file by the same name already exists. Do you want to replace it?" will appear. Click Yes.

You may now run the software from *Start/Programs/AFT Products* and selecting the product being leaseed, or by double clicking the application icon on your desktop.